

ENVIROSOLV_{TM}

WATER-BASED CLEANER

GENERAL DESCRIPTION

ENVIROSOLVTM is a water-based ink cleaner designed for the removal of water-based and plastisol inks. This product works especially well at opening up dried-in waster-base ink in the image area. This product will protect the fabric from deep stains or ghosting from the image print.

ADVANTAGES

- **Water Based**
- Non-Hazardous
- No Residue
- Pleasant Odor
- **Drain Safe**

Quick Tip:

To cut down on the number or rags it takes to clean a screen, use a non absorbent scrub pad to liquify the ink and a squeegee to pull all the ink to one end of the screen and wipe up with one or two rags.

Polypropylene EconoBooth

APPLICATIONS

Always card excessive ink from screen. Use one of the following applications.

"PRESS WASH/SCREEN OPENER"

Apply product on both sides of screen and then wipe or squeegee off until all residue is gone. ENVIROSOLVTM works extremely will when cataloging the screen.

"SCREEN WASH"

Apply to the ink side of the screen. Use a brush or pad to agitate both sides of the screen. High pressure water rinse until all residue is gone.



Look For More Information on all the Products in the ENVIROLINETM of "Green" Chemistry.













