## Applying TB-HV Pallet Adhesive



TB-HV can be quickly applied to the pallet

A thin bead of TB-HV is applied to the top of the pallet





Use the supplied squeegee to quickly spread adhesive down length of Pallet

Continue to spread the adhesive across the pallet





TB-HV dries in seconds and allows printing of dozens of shirts without re-application

Tekmar P.O. Box 4700 Santa Barbara, CA 93140, USA Toll Free 800 564 1096 Tel: 805/965 0704 Fax: 805/963 7794 www.tekmarltd.com

© 2004 TECHNICAL MARKETING, LIMITED